## **Line Tracer 09**

- Tachometer -

### This lecture is based on

- <u>Timers</u>
- Tachomter

### 1. Tachomter

#### What is Tachometer?

#### **Definition**


" A tachometer is an instrument measuring the rotation of a shaft or disk"

What can we do with a tachometer?


- We can measure RPM (rotations per minute) of the robot


### **TI-RSLK Tachometer**







#### **TI-RSLK Tachometer**





#### **Timer A Input Capture**






When an external event occurs, TIMER\_A3->CCR[0] = TIMER\_A3->TA0R & Timer interrupt occurs

**Output Compare** 

**Input Capture** 

When an event occurs, the counter value is stored in the CCR!


### **Tachometer & Timer's Input Capture**



Period

= Previous CCR - Current CCR

**Timer Interrupt Handler** 



#### **Initialization**

```
void timer_A3 capture_init() {
   P10->SEL0 = 0x30;
    P10->SEL1 &= ~0x30;
                                    alternative mode
    P10->DIR &= ~0x30;
    TIMER A3->CTL &= \sim 0 \times 0030;
    TIMER A3->CTL = 0x0200;
                                             setup timer &
    TIMER_A3 -> CCTL[0] = 0x4910;
                                          input capture mode
    TIMER A3->CCTL[1] = 0x4910;
    TIMER A3->EX0 &= \sim0x0007;
   NVIC->IP[3] = (NVIC->IP[3]&0x0000FFFF) | 0x404000000;
                                                                      configure interrupts
    NVIC \rightarrow ISER[0] = 0x0000C000;
    TIMER A3->CTL = 0 \times 0024;
```

### **Interrupt Handler**

```
uint16 t first left;
uint16 t first right;
uint16 t period left;
uint16 t period right;
void TA3_0_IRQHandler(void) {
    TIMER A3->CCTL[0] &= ~0x0001;
    period right = TIMER_A3->CCR[0] - first_right;
    first right = TIMER A3->CCR[0];
void TA3_N_IRQHandler(void) {
    TIMER A3->CCTL[1] &= ~0x0001;
    period left = TIMER A3->CCR[1] - first left;
    first left = TIMER A3->CCR[1];
```

#### **Measure RPM**

```
uint32_t get_left_rpm() {
    return 2000000 / period_left;
}
```

$$RPM = \frac{1^{\circ}}{360^{\circ}} * \frac{1}{period} * \frac{60s}{1m} * \frac{1}{timer\ cycle} * \frac{1,000,000,000ns}{s}$$

#### 180° Wheel Rotation


```
uint32_t left_count;
void TA3_N_IRQHandler(void) {
    TIMER_A3->CCTL[1] &= ~0x0001;
    left_count++;
}
```

```
while (1) {
    if (left_count > 180) {
        move(0, 0);
    }
};
```


## Please Upload LMS

3. Activity

### **Robot Spec**



# 1. Go Straight 30cm



### 2. Rotate 30°(Assignments)

